

Open 'Zone' section.

Configure Zone 1 to desired schedule for 1st door(s).

Set 'LINK' to 'END'.

Select desired door node (if multiple doors, must send one at a time.)

Click 'Send'.

While remaining on Zone 1, change start/end times to reflect desired schedule for 2nd door(s).

Ensure that 'LINK' is still set to 'END'.

Select desired door node (if multiple doors, must send one at a time.)

Click 'Send'.

Open 'Users' section.

Apply Zone 1 to user(s) intended to follow said door schedules.

Click 'save'.

****PLEASE NOTE:** After this configuration is set, you CANNOT use 'all items' option in the 'DNLD' section. This will negate the concurrent door schedules.